POWERFUL CLEANER FOR STERNDRIVES AND OUTBOARD SHAFTS



DESCRIPTION

Professional cleaner specially developed for deep cleaning of stern drives and outboard shafts. It removes effectively lime scale, algae, barnacles and seaweed.

- To use on stern drives and outboard engine shafts.
- Removes algae, green deposits, seaweed & barnacles.
- Very powerful formula.

INSTRUCTIONS

- 1. Apply DULON STERNDRIVE & OUBOARD SHAFT CLEANER 30 using a soft brush or sponge or low-pressure pump and spread thinly over the surface.
- 2. Allow 10 minutes to take effect (prevent drying out).
- 3. Scrub with hard brush or scouring pad.
- 4. Rinse with clean water, preferably using a high pressure spray.

In case of severe pollution repeat the treatment.

AVAILABLE PACKAGING

Article number	Product	Packaging	Content
6-30010	Dulon Sterndrive & Outboard Shaft Cleaner 30	Flacon	1L
6-30050	Dulon Sterndrive & Outboard Shaft Cleaner 30	Can	5L
6-30250	Dulon Sterndrive & Outboard Shaft Cleaner 30	Can	25L

TIPS & TRICKS

• Also excellent for removing green deposits on your motor home, caravan, terrace and driveway.

C.R.P. INDICATOR

• Clean.

STORAGE & USE

- Store frost-free, in a dark and dry place .
- Apply above 0°C.
- do not use in direct sun light.

YOU MAY ALSO LIKE

- Dulon Hull & Waterline Clean 22.
- Dulon Boatbottom Clean 24.

RELATED PRODUCTS

٠

PDS – Dulon Sterndrive & Outboad Shaft Cleaner 30



Dulon Marine Energieweg 12 2382NJ Zoeterwoude The Netherlands I www.dulonmarine.com E info@dulonmarine.com POWERFUL CLEANER FOR STERNDRIVES AND OUTBOARD SHAFTS



HAZARD + PRECAUTIONARY STATEMENTS



GHS05 - DANGER

H314 Causes severe skin burns and eye damage.

P280 Wear protective gloves/protective clothing/eye protection/face protection.

P301+P330+P331 IF SWALLOWED: rinse mouth. Do NOT induce vomiting.

P303+P361+P353 IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water/shower.

P304+P340 IF INHALED: Remove person to fresh air and keep comfortable for breathing.

P305+P351+P338 IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

P310 Immediately call a POISON CENTER/doctor.

P405 Store locked up.

P501 Dispose of contents/container in accordance with local/regional/national/international regulations.



Dulon Marine Energieweg 12 2382NJ Zoeterwoude The Netherlands I www.dulonmarine.com E info@dulonmarine.com