

# DULON TEAK CLEAN & BRIGHTENER 42



## TEAK CLEANER & COLOR RESTORER

### DESCRIPTION

Phase 2 of the 3-STEP TEAK CARE SYSTEM

Cleaner for teak, removes limescale, algae and green deposits and restores the original color of teak (deck) or furniture.

- Removes limescale, green deposits and algae.
- Restores the original color.
- Water-based formula.
- Suitable for all types of hardwood.

### INSTRUCTIONS

1. Apply DULON TEAK CLEAN & BRIGHTENER 42 pure or diluted (1:1) to the teak(deck) or furniture.
2. Allow 5 minutes to take effect (prevent dehydration).
3. Scrub with soft brush or scrub pad.
4. Rinse off with water.

Proceed process with phase 3 of the DULON 3-STEP TEAK CARE SYSTEM:

Impregnate and protect with DULON TEAK PROTECTOR 43.

### AVAILABLE PACKAGING

Article number	Product	Packaging	Content
6-42010	Dulon Teak Clean & Brightener 42	Flacon	1L
6-42050	Dulon Teak Clean & Brightener 42	Can	5L
6-42250	Dulon Teak Clean & Brightener 42	Can	25L

### TIPS & TRICKS

- Also ideal to treat wooden garden furniture.
- Proceed process with phase 3 of the DULON 3-STEP TEAK CARE SYSTEM: Impregnate and protect with DULON TEAK PROTECTOR 43.

### C.R.P. INDICATOR

- Clean.
- Restore.

### STORAGE & USE

- DULON TEAK CLEAN & BRIGHTENER 42 (1L) treats a maximum of 10m<sup>2</sup>.
- Store frost-free, in a dark and dry place .
- Apply above 0°C.
- do not use in direct sun light.

### YOU MAY ALSO LIKE

- 



# DULON TEAK CLEAN & BRIGHTENER 42

TEAK CLEANER & COLOR RESTORER



## RELATED PRODUCTS

- Dulon Teak Degreaser 41.
- Dulon Teak Protector 43.

## HAZARD + PRECAUTIONARY STATEMENTS



GHS05 - DANGER

H314 Causes severe skin burns and eye damage.

P280 Wear protective gloves/protective clothing/eye protection/face protection.

P301+P330+P331 IF SWALLOWED: rinse mouth. Do NOT induce vomiting.

P303+P361+P353 IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water/shower.

P304+P340 IF INHALED: Remove person to fresh air and keep comfortable for breathing.

P305+P351+P338 IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

P310 Immediately call a POISON CENTER/doctor.

P405 Store locked up.

P501 Dispose of contents/container in accordance with local/regional/national/international regulations.

